

Minimum Plain Bore Bushings



QD Style

Part#	Bore Size
JAMPB	1/2
SHMPB	1/2
SDSMPB	1/2
SDMPB	1/2
SKMPB	1/2
SFMPB	1/2
EMPB	7/8
FMPB	1
JMPB	1 1/2
MMPB	2
NMPB	2 7/16
WMPB	4



DST Style

Part#	Bore Size
GMPB	3/8
HMPB	3/8
P1MPB	1/2
P2MPB	3/4
Q1MPB	3/4
Q2MPB	1
R1MPB	1 1/8
R2MPB	1 3/8



TB Style

Part#	Bore Size	Keyway
1008MPB	1/2	1/8 x 1/16
1108MPB	1/2	1/8 x 1/16
1210MPB	1/2	1/8 x 1/16
1215MPB	1/2	1/8 x 1/16
1310MPB	1/2	1/8 x 1/16
1610MPB	1/2	1/8 x 1/16
1615MPB	1/2	1/8 x 1/16
2012MPB	1/2	1/8 x 1/16
2517MPB	1/2	1/8 x 1/16
2525MPB	7/8	3/16 x 3/32
3020MPB	15/16	1/4 x 1/8
3030MPB	15/16	1/4 x 1/8
3535MPB	1 3/16	1/4 x 1/8
4040MPB	1 7/16	3/8 x 3/16
4545MPB	1 15/16	1/2 x 1/4
5050MPB	2 7/16	5/8 x 5/16

Replacement Bolt Kits for Bushings

Bushing	Bolt Kit P/N	Bushing	Bolt Kit P/N
1008	1008BK	P1	P1BK
1108	1108BK	P2	P2BK
1210	1210BK	Q1	Q1BK
1215	1215BK	Q2	Q2BK
1310	1310BK	R1	R1BK
1610	1610BK	R2	R2BK
1615	1615BK	JA	JABK
2012	2012BK	SH	SHBK
2517	2517BK	SDS	SDSBK
2525	2525BK	SD	SDBK
3020	3020BK	SK	SKBK
3030	3030BK	SF	SFBK
3535	3535BK	E	EBK
4040	4040BK	F	FBK
4545	4545BK	J	JBK
5050	5050BK	M	MBK
G	GBK	N	NBK
H	HBK	P	PBK

Note: Each kit contains bolts and washers for one bushing.

Note: MPB bushings are unsplit and unless noted have no keyway for ease of machining. Bushings must be saw cut prior to use.